

*Directions for operating Silicon Pipette Filler*

- 1) Press Button “A” at top of filler and squeeze bulb to evacuate air from the bulb.
- 2) Release Button “A” once air is evacuated from bulb.
- 3) Press Button “S” located under bulb to pull liquid into pipette.
- 4) Press “E” button located on the extending portion of the Pipette Filler to empty the pipette.
- 5) Squeeze the bulb located directly under “S” valve to expend any remaining liquid from bulb.

