



Electronic Metering Pumps

Series A PLUS

Key Features

- **Manual Control** by on-line adjustable stroke rate and stroke length.
- **Agency approved** for demanding **OUTDOOR** and indoor applications.
- **Highly Reliable** timing circuit.
- **Water Resistant** excellent for **OUTDOOR** and indoor applications.
- **Internally Dampened To Reduce Noise**, very acceptable for household installations.
- **Guided Ball Check Valve Systems**, to reduce back flow and enhance outstanding priming characteristics.
- **Premium Standard Wetted Component Materials.**
- **Few Moving Parts** and **Wall Mountable.**
- **Safe & Easy Priming** with durable leak-free bleed valve assembly (standard).
- **Optional Control:**
 - External pace with auto/manual selection.
 - External stop function
 - 1000:1 turndown control (S2, S3 & S4 sizes only)



Pressure and Flow Rate Capacity



MODEL			LBC2	LB02	LBC3	LB03	LB04	LB64	LBC4	LBS2	LBS3	LBS4	
Capacity nominal (max.)		GPH	0.25	0.25	0.42	0.50	1.00	1.25	2.00	0.50	1.38	2.42	
		GPD	6	6	10	12	24	30	48	12	33	58	
		LPH	0.9	0.9	1.6	1.9	3.8	4.7	7.6	1.9	5.2	9.14	
Pressure ¹ (max.)	GFPP, PVDF, 316SS or PVC (W code) w/TFE Seats	PSIG (Bar)	250 (17)	150 (10)	250 (17)	150 (10)	100 (7)	100 (7)	50 (3.3)	250 (17)	150 (10)	100 (7)	
	PVC (V code) Viton or CSPE Seats / Degas Liquid End		150 (10)										
Connections		Tubing	1/4" ID X 3/8" OD						3/8" ID X 1/2" OD	1/4" ID X 3/8" OD			
		Piping	1/4" FNPT										
Strokes/Minute		SPM	125								250		

Note 1: Pumps with rated pressure above 150 PSI will be de-rated to 150 PSI Max. when selecting certain valve options, see Price Book for details.

Engineering Data

Reproducibility:	+/- 3% at maximum capacity
Viscosity Max CPS:	1000 CPS
Stroke Frequency Max SPM:	125 / 250 by Model
Stroke Frequency Turn-Down Ratio:	10:1 / 100:1 by Model
Stroke Length Turn-Down Ratio:	10:1
Power Input:	115 VAC/50-60 HZ/1 ph 230 VAC/50-60 HZ/1 ph
Average Current Draw:	
@ 115 VAC; Amps:	0.6 Amps
@ 230 VAC; Amps:	0.3 Amps
Peak Input Power:	130 Watts
Average Input Power @ Max SPM:	50 Watts



sales@novatech-usa.com
www.novatech-usa.com
 Tel: (866) 433-6682 Fax: (866) 433-6684
 Tel: (281) 359-8538 Fax: (281) 359-0084

Pulsatron Series A Plus Model Selection Matrix

Pulsatron Series A Plus Selection Guide

Models

Product Code	Flow Rate			Pressure Rating ¹		Stroke Rate	Standard Valve	Max. Viscosity	
	GPD	GPH	LPH	PSI	BAR	(SPM)	Size	(cps)	
S2	12	0.50	1.9	250	17	250	J (Teflon Only)	1,000	
S3	33	1.38	5.2	150	10		1		
S4	58	2.42	9.1	100	7				
C2	6	0.25	0.9	250	17	125	J (Teflon only)		
C3	10	0.42	1.6						
02	6	0.25	0.9	150	10				
03	12	0.50	1.9						
04	24	1.00	3.8	100	7				
64	30	1.25	4.7				1		
C4	48	2.00	7.6	50	3.3				3

Controls

S	Manual, Control, Analog Adjustment	100:1 Turndown	10:1 Stroke Length 10:1 Frequency
E	External Pace w/ Auto/Manual Switch		
P	Stop Function Option		
X	Manual Control, Analog Adjustment (S2, S3 & S4 sizes only)	1000:1 Turndown	10:1 Stroke Length 100:1 Frequency

Electrical

A	115 VAC, 60Hz
B	230 VAC, 50-60Hz, 1 Ph, 6' (2m) cord with 3 prong US plug
1	115 VAC, 60Hz less Agency Approvals
2	230 VAC, 50-60Hz, 1 Ph, 6' (2m) cord, no plug, less Agency

Liquid End Configuration - Head & Valves / Seats & O-Rings / Check Balls

PHC	GFPPL / CSPE / Ceramic (150 PSI Max) ¹
PTC	GFPPL / TFE / Ceramic
VTC	PVC / TFE / Ceramic (150 PSI Max) ¹
WTC	PVC / TFE / Ceramic (models > 150 PSI Max); For use on S2, C2, C3
KTC	PVDF / TFE / Ceramic
VVC	PVC / Viton / Ceramic (Not available with J Valve) (150 PSI Max) ¹
VHC	PVC / CSPE / Ceramic (Not available with J Valve) (150 PSI Max) ¹
Other	See Page 4 for additional materials of construction

Connection Sizes

J	Tubing .25" I.D. x .38" O.D. Standard for pumps from 0 - 33 GPD
1	Tubing .25" I.D. x .38" O.D. Standard for pumps from 20 - 45 GPD
3	Tubing .38" I.D. x .50" O.D. Standard for pumps from 45 - 240 GPD
9	Degas Head: Vent Tubing .25" I.D. x .38" O.D. (0-150 PSI pumps only)
Metric	
R	G 1/2 A Threads, .25" Ball, 0-7.1 LPH
Y	Tubing 6 x 12mm, .25" Ball, 0-7.1 LPH
Other	See Page 5 for additional connection options


Options

XXX	Standard Pump - No Options
130	PVDF Tubing
500	Five Function Valve
520	Five Function Degassing Valve
ITS	15 gal. ITS Tank System
CZXXX	CE Listed

See pages 7, 8 & 9 for additional information and specs.

Note 1: Pumps with rated pressure above 150 PSI will be de-rated to 150 PSI Max. when selecting these valve options.

Dimensions



Series A PLUS Dimensions (inches)						
Model No.	A	B	C	D	E	Shipping Weight
LB02 / S2	5.0	9.6	9.5	6.5	8.2	10
LBC2	5.0	9.9	9.5	6.5	8.5	10
LBC3	5.0	9.9	9.5	6.5	8.5	10
LB03 / S3	5.0	9.9	9.5	6.5	8.5	10
LB04 / S4	5.0	9.9	9.5	6.5	8.5	10
LB64	5.0	9.9	9.5	6.5	8.5	10
LBC4	5.0	9.9	9.5	6.5	8.5	10

NOTE: Inches X 2.54 = cm

PULSAtron® *Model Selection Guide*


Once you have selected the appropriate Series, you must configure the model so that it is built with the features you desire. The Configuration Guide associated with each Series will present the most popular selections. Select one code from each category to build up a complete model string.

To help you better understand the model string, in the following pages, we will explain what each of the digits represent and provide you some additional charts to help you select options not found in the Configuration Guides.

Model Selection:


The first four digits represent the Series and Flow/Pressure Selection.

LB02



The first digit will always start with the letter 'L'.

LB02




All PULSAtron models begin with this letter. The second letter designates the Series (e.g. Series MP, Series E+, Series A+, etc.). Each series has a different set of features that are available in terms of control and flow/pressure capacity. The next two digits represent the flow/pressure capacity of the pump.

Digits 3 & 4 represent the Flow/Pressure Code.

This code represents the specific flow/pressure rating for the model and can be found in the specification for each Series.

Series Code Designator	
Series MP	M
Series E Plus	P
Series HV	V
Series E	E
Series E-DC	S
Series D	F
Series A Plus	B
Series C Plus	D
Series C & T7	C
Series CW	W
Series CL	L
Series WT	Q
Series ET	T

LB02SA



Digits 5 & 6 represent the Controls and Electrical selections.

These selections are explained for each model in the Configuration Guide.



Selection Guide cont'd.

Selecting the Wet-End Code & Connection Type:

Digits 7-10 in the string represent the wet-end code. It is the group of four digits set apart by the dash lines.

LB02SA-PTC1



These four digits represent your wet-end code and connection type.

The four digits in the wet-end code represent the Head Material, Seats & O-Rings, Ball Material and Connection type. Using the above example, the code breaks down as follows:

- P** - Head Material, including fittings. In this example, the P represents GFPPL.
- T** - Seat & O-Ring Material. In this example, the T represents TFE.
- C** - Types of Balls used in the valves. In this example, the C represents Ceramic.
- 1** - Connection type. In this example, the 1 represents tubing connections for 3/8" OD tubing.

In the configuration Guide, we have listed the most popular Wet-End codes. If you don't find the materials or connection selection to meet your needs, refer to the following selection guides to configure the proper Wet-End Code.

Selecting the Wet-End Code:

The wet-end code represents the materials of construction that will be in contact with the chemical you are pumping. It is critical that the materials selected are compatible. If you do not find the wet-end code to meet your application in the configuration guides, you can use the Wet-End Code Selection Guide to determine the correct Head Material, Seats & O-Rings and Balls. If you do not know what materials are compatible with the chemicals you are pumping, refer to the chemical compatibility chart below. We have identified the proper wet-end code for the chemicals in the list. If your chemical is not found in the list, please contact your chemical supplier or visit www.pulsatron.com for a complete listing.

PULSAtron Wet-End Code Selection

Head & Fittings

- A** = 316 Stainless Steel (All models except H8)
- K** = PVDF (Kynar) (Consult factory for J7, H8 models)
- P** = GFPPL (Polypropylene)
- V** = PVC (Poly Vinyl Chloride) (for models rated < 150 psi excluding K7, H7, H8)
- W** = PVC (for models > 150 psi and K7, H7, H8)

Seats

- H** = CSPE
- T** = TFE (not available with TFE ball over 150 psi)
- V** = Viton (150 psi max.)

Balls

- C** = Ceramic
- H** = Alloy C (Hastelloy)
- S** = 316 Stainless Steel
- T** = TFE (not available with TFE seat over 150 psi)

Chemical Compatibility Chart

Chemical	Liquid End Code
ACETIC ACID, 5 - 10%	PHC
ALUMINUM SULFATE	VHC
AMMONIA, 10%	PHC
BROMINE	KTC
CALCIUM HYPOCHLORITE	VVC
CITRIC ACID, 10 - 20%	PHC
DEAE - Steamline Treatment	ATS
ETHYLENE GLYCOL	PTC
FERRIC CHLORIDE	VTC
FERRIC SULFATE	PTC
FLUOSILICIC ACID	PTT
HYDROCHLORIC ACID, 0 - 37%	PTC
HYDROCHLORIC ACID, 37 - 100%	KTT
HYDROFLUOSILICIC ACID, 20%	PTT
HYDROGEN PEROXIDE, 0 - 30%	VVC
LACTIC ACID	PTC
NITRIC ACID, 0 - 20%	PVC
PHOSPHORIC ACID, 0 - 100%	KTC
POTASSIUM CHLORIDE	PTC
POTASSIUM PERMANGANATE	PTC
SODIUM BI-CARBONATE	PTC
SODIUM BI-SULFATE	PTC
SODIUM BI-SULFITE	PTC
SODIUM CARBONATE	PTC
SODIUM HYDROXIDE, 0 - 50%	PHC
SODIUM HYPOCHLORITE	VVC
SODIUM NITRATE	PTC
SODIUM SILICATE	PHC
SODIUM SULFATE	PHC
SODIUM SULFIDE	PHC
SULFURIC ACID, 0 - 10%	PTC
SULFURIC ACID, 10 - 75%	PTC
SULFURIC ACID, 95 - 100%	KTC

This is an abbreviated version using most common chemicals. Refer to the Chemical Resistance Guide (EMP-030) for a more detailed listing.

Model Selection Guide (Connection Size Codes)

Selecting the Connection Code:

Selecting the proper connection code is probably the most difficult part of choosing a PULSAtron pump. Because of the flexibility built into this product line to meet a large variety of applications, the connection codes are determined by a lot more factors than just the size of the tubing. Connection code is probably the wrong name for this selection because you are selecting more than just the tubing size. This code also determines the type of valves used in the pump. The valve type is determined by factors such as flow rate of the pump, ball type selected and viscosity of the fluid you will be pumping.

Flow Rate:

The pump you select is rated to pump a certain number of gallons per hour (GPH). When selecting the connection code, please note the GPH limitations and select a connection that fits within the parameters of the pump model that you selected.

Ball Type:

If the material selected for the balls used in the check valves is TFE, you will probably need to use a spring-loaded connection. This is due to the fact that the weight of the balls will not allow them to seat properly without the spring. See the connection chart for a list of spring loaded connection types.

Viscosity:

Viscosity of the fluid you are pumping impacts the connection. The higher viscosity fluids (>3000 cps) require larger connection types and spring-loaded valves. Medium viscosity fluids (1000 to 3000 cps) can be pumped without the spring-loaded valves but you must use SS balls with these connections in order for the balls to seat properly in the valve.

Connection Codes

Code	Connect Type	Suction	Discharge	Spring	GPH Flow Limitations	Viscosity	Other Factors
2	Piping	.25" FNPT	.25" FNPT		0 - 1.88	1000 up to 3000 cps w / SS balls	No Bleed Valve
4	Piping	.25" FNPT	.25" FNPT		1.63 - 10	1000 up to 3000 cps w / SS balls	No Bleed Valve
6	Piping	.25" FNPT	.25" FNPT	Yes	Up to 10	less than 10,000 cps	No Bleed Valve
8	Piping	.50" FNPT	.50" FNPT	Yes	Up to 25	less than 10,000 cps	No Bleed Valve
C	Piping	.50" FNPT	.50" FNPT		25	1000 up to 3000 cps w / SS balls	No Bleed Valve
G	Piping	.25" FNPT	.25" FNPT	Yes	0 - 1.88	1000 up to 3000 cps w / SS balls	No Bleed Valve
I	Piping	.50" MNPT	.50" MNPT	Yes	Up to 10	less than 10,000 cps	No Bleed Valve
L	Piping	.50" MNPT	.50" MNPT		0 - 1.88	1000 up to 3000 cps w / SS balls	No Bleed Valve
X	Piping	.50" MNPT	.50" MNPT		1.63 - 10	1000 up to 3000 cps w / SS balls	No Bleed Valve
1	Tubing	.25" x .38"	.25" x .38"		0 - 1.88	1000 up to 3000 cps w / SS balls	
3	Tubing	.38" x .50"	.38" x .50"		1.63 - 10	1000 up to 3000 cps w / SS balls	
5	Tubing	.50" x .75"	.38" x .50"	Yes	Up to 10	less than 10,000 cps	
7	Tubing	.50" x .75"	.50" FNPT	Yes	Up to 25	less than 10,000 cps	No Bleed Valve
9	Tubing	.25" x .38"	.25" x .38"	Yes	0 - 1.88	1000 up to 3000 cps w / SS balls	Degas Head/No Bleed Valve
A	Tubing	.38" x .50"	.38" x .50"		0 - 1.88	1000 up to 3000 cps w / SS balls	
B	Tubing	.50" x .75"	.50" x .75"		25	1000 up to 3000 cps w / SS balls	No Bleed Valve
D	Tubing	.25" x .38"	.25" x .38"	Yes	0 - 1.88	1000 up to 3000 cps w / SS balls	
E	Tubing	.38" x .50"	.38" x .50"	Yes	0 - 1.88	1000 up to 3000 cps w / SS balls	
F	Tubing	.38" x .50"	.38" x .50"	Yes	1.63 - 10	1000 up to 3000 cps w / SS balls	Not Available In PVDF
H	Tubing	.25" x .38"	.25" x .38"		1.63 - 10	1000 up to 3000 cps w / SS balls	
J	Tubing	.25" x .38"	.25" x .38"		0 - 1.04	1000 up to 3000 cps w / SS balls	
K	Tubing	.50" x .75"	.50" x .75"	Yes	1.88 - 25 (<50 psi)	less than 10,000 cps	No Bleed Valve
					LPH Flow Limitations		
M	Piping	G 1/2 A	G 1/2 A		6.15 - 37.85	1000 up to 3000 cps w / SS balls	
R	Piping	G 1/2 A	G 1/2 A		0 - 7.10	1000 up to 3000 cps w / SS balls	
N	Tubing	4 x 10 mm	4 x 10 mm		0 - 7.10	1000 up to 3000 cps w / SS balls	
P	Tubing	4 x 6 mm	4 x 6 mm		0 - 3.94	1000 up to 3000 cps w / SS balls	
Q	Tubing	10 x 14 mm	10 x 14 mm		6.15 - 37.85	1000 up to 3000 cps w / SS balls	
S	Tubing	6 x 10 mm	6 x 10 mm		> 18.93	1000 up to 3000 cps w / SS balls	
T	Tubing	6 x 10 mm	6 x 10 mm		0 - 7.10	1000 up to 3000 cps w / SS balls	Degas Head/No Bleed Valve
U	Tubing	6 x 10 mm	6 x 10 mm		0 - 7.10	1000 up to 3000 cps w / SS balls	
V	Tubing	12 x 19 mm	12 x 19 mm		> 29.96	1000 up to 3000 cps w / SS balls	No Bleed Valve
W	Tubing	10 x 16 mm	10 x 16 mm		6.15 - 37.85	1000 up to 3000 cps w / SS balls	
Y	Tubing	6 x 12 mm	6 x 12 mm		0 - 7.10	1000 up to 3000 cps w / SS balls	

- Pumps ranging from 0.25 gph (0.9 lph) to 0.90 gph (3.4 lph) with the stainless steel ball option ("S" in the 9th digit of the model number) must select a connection code with a spring.
- Pumps less than or equal to .25 gph (0.9 lph) require a connection code with a spring and must use a ceramic ball in place of stainless steel.
- Stainless steel head assemblies are only available in piping connections.



Selection Guide cont'd.

Suffix Code:

LB02SA-PTC1-XXX ← Suffix Code

The last three digits of the model string are referred to as the Suffix Code. It is through the suffix code that the pump can be customized with optional features or customer specific features, e.g. private labeling. If your company has specific features that will be ordered on every pump, contact customer service with a description of what you want customized. We will then assign a unique suffix code that can be used as the last three digits in the model string when you place an order.

CZXXX = CE Approval

This suffix code tells us that you require CE Approval on the pump you are ordering. This suffix code is five digits and can be used in conjunction with other suffix codes by replacing the XXX after the CZ with another suffix code. For instance, if you require CE Approval and a Five Function Valve (shown below), the suffix code would be CZ500.

Standard Suffix Code Descriptions:

On the following pages are additional features that can be added to your PULSAtron pump through the use of the Suffix Code. Anytime you order a pump with one of these codes, it will be configured with that option.

130 = PVDF Tubing


This suffix code will replace the standard pump tubing with PVDF Tubing.

500 = Five Function Valve

The five function valve is easily installed, no tools required. The valve operates with all PULSAtron models up to 240 GPD. The five function valve is packed with features that increase safety, enhance performance and generally improves the convenience of operation.

FEATURES

- Pressure Relief – Allows for relief of excessive pressure in discharge line to protect connections and tubing.
- Back Pressure – Maintains output reproducibility and allows metering into atmospheric discharge.
- Anti-Siphon – Prevents siphoning through the pump when point of injection is lower than the pump or into the suction line of another pump. Rated at total vacuum.
- Air Bleed – Used during priming to manually remove air from the pump head.
- Discharge Drain – Depressurize pump discharge line without loosening tubing or fittings. Protects the operator from chemical exposure.



SPECIFICATIONS

Material Of Construction:

Valve Body	Polyvinylidene Flouride (PVDF)
Diaphragm	TFE faced CSPE
O-Rings	TFE
Hardware	18-8 Stainless Steel (Recessed)

Maximum Operating

Pressure: 300 PSI/21 BAR (except PVC)

Maximum Flow: 10 GPH (37.85 LPH)

Maximum Viscosity: 1000 CPS

Pressure Relief

Settings:
 (nominal cracking pressure)
 275 PSI (17 BAR) - red
 175 PSI (12 BAR) - green
 125 PSI (8.6 BAR) - blue
 50 PSI (2.8 BAR) - black (PVC only)

Note: Pressure relief will occur at no more than 50% above maximum rating of pump.

OPERATION

The functions are selected by setting two dual position selector knobs. The label on the back panel of the valve identifies each function with selector knob positions.

The five function valve is compatible with most PULSAtron pumps. Connected to the existing discharge valve the five function valve is capable of handling a large output flow as well as viscous liquids. A return port located on the side body provides flow of chemical back to the solution tank when in the air bleed or drain discharge mode.



Selection Guide cont'd.


520 = DG/5FV Five Function

Valve with De-Gas

With the DG/5FV you don't have to give up the accuracy and control of a solenoid metering pump in order to pump gaseous solutions. Available in a variety of materials and popular sizes, the DG/5FV is ready to tackle most applications. Not only does the DG/5FV provide degassing, it is packed with features that increase safety, enhance performance and generally improves the convenience of operation.

FEATURES

- De-Gas – Bypass gasses and fluid during normal pump operation. Allows for the constant removal of gases that would otherwise “air bind” the pump.
- Back Pressure – Maintains output reproducibility and allows metering into atmospheric discharge.
- Anti-Siphon – Prevents siphoning through the pump when point of injection is lower than the pump or into the suction line of another pump. Rated at total vacuum.
- Air Bleed – Used during priming to manually remove air from the pump head.
- Discharge Drain – Depressurize pump discharge line without loosening tubing or fittings. Protects the operator from chemical exposure.



SPECIFICATIONS

Material Of Construction:

Valve Body	Polyvinylidene Flouride (PVDF)
Diaphragm	TFE faced CSPE
O-Rings	Viton or CSPE
Hardware	18-8 Stainless Steel (Recessed)

Maximum Flow: 10 GPH (37.85 LPH)

Minimum Flow: 3 GPD (.47LPH)

Maximum Viscosity: 1000 CPS

MAX Pressure Ratings: Up to 250 psi (17 BAR)

Note: Degas/bypass volume is adjustable, typically 1-10% of pump output.

Connections: 1/4" (0.635 cm) Male NPT
1/2" (1.27 cm) OD tubing
3/8" (0.95 cm) OD tubing

All ports (input, output & bypass) on the selected valve will be the same.

OPERATION

The functions are selected by setting two dual position selector knobs. The label on the back panel of the DG/5FV identifies each function with selector knob positions.

The DG/5FV is compatible with most PULSAtron pumps. Connected to the existing discharge valve the GG/5FV is capable of handling a large output flow as well as viscous liquids. A return port located on the side body provides flow of chemical back to the solution tank when in the degas, air bleed or drain discharge mode.

ITS = Integrated Tank System

The ITS System is a completely integrated tank system constructed of high density UV resistant polyethylene (PE) with a 15 gallon capacity. This tank system is translucent with 5 gallon increments and the tank's low level indicator allows visual monitoring of chemicals without opening the tank. The tight fitting child-proof lid keeps the chemical free of contaminants and protects the surrounding area from chemical fumes.

The ITS System also allows for easy access to the liquid end and control panel of the mounted pump.

A system consists of a chemical tank with lid and bulkhead fittings; a liquid level indicator float assembly; and feeder mounting hardware.



ITS Tank not available on LM, LP, LT, and LE: H4, H5, H6, H7, J7, H8, K7 models) If you require a different type or size tank, please refer to our accessory price book.



Selecting a KOPkit:

All KOPkit model strings begin with the letter K. The remainder of the string can be determined by knowing your pump model.

When you select your KOPkit, you will need to build the model number based on the pump model string that you purchased. The two pieces of information you need are the head size and the wet-end code, which is part of the model string of the pump.

The pump head size is the fourth digit in the pump model number.

LB02SA-PTC1-XXX



The 2 represents your pump head size.

Digits 7-20 in the pump model string represent the wet-end code. It is the group of four digits set apart by the dash lines.

LB02SA-PTC1-XXX



These four digits represent your wet-end code.

In the following selection guide, you will break down your wet-end code into the four parts to get your total price for the KOPkit. The four digits in the wet-end code represent the Head Material, Seats & O-Rings, Ball Material and Connection Type. Using the above example, the code breaks down as follows:

P - Head Material, including fittings. In this example, the P represents GFPPL.

T - Seat & O-Ring Material. In this example, the T represents Teflon.

C - Types of Balls used in the valves. In this example, the C represents Ceramic.

1 - Connection type. In this example, the 1 represents tubing connections for 3/8" OD tubing.

The completed KOPkit number for the above example is:

K2PTC1

Note: If you do not find your connection size in the following selection guide, please consult the factory for accurate pricing. Our philosophy with the PULSAtron product line is to make it as flexible as our customers need it to be.

Model Selection Guide (KOPkit - Liquid End Parts Kit Matrix)



PULSAtron KOPkit Selection

HEAD SIZE

The digits 2-8 follow ing the K represents the pump head size.

This is represented by the fourth digit in the pump model string.

- 2 =
- 3 =
- 4 =
- 5 =
- 6 =
- 7 =
- 8 = (Applies to WTCB only-for other options Consult factory)

HEAD MATERIALS

- A = 316 Stainless Steel
- K = PVDF (Kynar)
- P = GFPP (Polypropylene)
- V = PVC (Poly Vinyl Chloride) (models <= 150 psi excluding H7, H8, K7)
- W = PVC (models > 150 psi and H7, H8, K7)

SEATS/O-RINGS

- H = CSPE
- V = Viton
- T = TFE

BALLS

- T = TFE
- C = Ceramic
- S = 316 Stainless Steel
- H = Alloy C (Hastelloy)

CONNECTION TYPE

Type	Suction	Discharge	Spring
1 = Tubing	.25" x .38"	.25" x .38"	
2 = Piping	.25" FNPT	.25" FNPT	
3 = Tubing	.38" x .50"	.38" x .50"	
4 = Piping	.25" FNPT	.25" FNPT	
5 = Tubing	.50" x .75"	.38" x .50"	Yes
6 = Piping	.25" FNPT	.25" FNPT	Yes
7 = Tubing	.50" x .75"	.50" FNPT	Yes
8 = Piping	.50" FNPT	.50" FNPT	Yes
9 = Tubing	.25" x .38"	.25" x .38"	Yes Degas
A = Tubing	.38" x .50"	.38" x .50"	
B = Tubing	.50" x .75"	.50" x .75"	
C = Piping	.50" FNPT	.50" FNPT	
D = Tubing	.25" x .38"	.25" x .38"	Yes
E = Tubing	.38" x .50"	.38" x .50"	Yes
F = Tubing	.38" x .50"	.38" x .50"	Yes
G = Piping	.25" FNPT	.25" FNPT	Yes
I = Piping	.50" MNPT	.50" MNPT	Yes
J = Tubing	.25" x .38"	.25" x .38"	
K = Tubing	.50" x .75"	.50" x .75"	Yes
L = Piping	.50" MNPT	.50" MNPT	
M = Piping	G 1/2 A	G 1/2 A	
N = Tubing	4 x 10 mm	4 x 10 mm	
P = Tubing	4 x 6 mm	4 x 6 mm	
Q = Tubing	10 x 14 mm	10 x 14 mm	
R = Piping	G 1/2 A	G 1/2 A	
S = Tubing	6 x 10 mm	6 x 10 mm	
T = Tubing	6 x 10 mm	6 x 10 mm	Degas
U = Tubing	6 x 10 mm	6 x 10 mm	
V = Tubing	12 x 19 mm	12 x 19 mm	
W = Tubing	10 x 16 mm	10 x 16 mm	
Y = Tubing	6 x 12 mm	6 x 12 mm	
X = Piping	.50" MNPT	.50" MNPT	



Suction/Discharge Valves

Suction/Discharge Valve Selection Guide		L3				
VALVE TYPE:	101 = Suction Valve 201 = Discharge Valve					
SEATS:	H = CSPE V = Viton T = TFE					
BALLS:	T = TFE C = Ceramic S = 316 Stainless Steel H = Alloy C (Hastelloy)					
CONNECTION TYPE:	1 = Double Balls w hen TFE seats selected 2 = Double Balls w hen TFE seats selected 3 = Double Balls w hen TFE seats selected 4 = Double Balls w hen TFE seats selected 5* = Available for Discharge Only (L3201) 6 = 7* = Available for Suction Only (L3101) 8 = A = B* = C = D = Spring Loaded w ith SS Balls E = Spring Loaded w ith SS Balls F = Spring Loaded w ith SS Balls G = Spring Loaded w ith SS Balls I = J = K* = L = M = N = P = Q = R = S = U = V* = W = Y = X =					
MATERIALS OF CONSTRUCTION:	FPP = Glass Filled Polypropylene PVC = Poly Vinyl Chloride PVC = Kynar 316 = 316 Stainless Steel					

* Available with Ceramic Balls and PVC Body Only - Consult factory for pricing on other options



Quick Reference Guide

This guide is designed to provide a simple, easy reference for ordering liquid end components used in many standard configurations. To use this chart, simply use positions 7, 8, 9, 10, 11, 12, and 13 from the model number on your pump. Match these digits to the chart below and follow the line across to determine the part numbers of the liquid end components that you need.

EXAMPLE

1	2	3	4	5	6	7	8	9	10	11	12	13
L	P	E	4	S	A	P	H	C	1	X	X	X

Liquid End Code

Positions 7 -13	Suction Valve Assembly	Discharge Valve Assembly	Bleed Valve Assembly	Foot Valve/Strainer Assembly	Injector Back Pressure Valve Assembly	Suction Tubing (by foot)	Discharge Tubing (by foot)
PTC1-XXX	L3101TC1-FPP	L3201TC1-FPP	L3300T01-FPP	J40211	J61098	00007	00010
PHC1-XXX	L3101HC1-FPP	L3201HC1-FPP	L3300H01-FPP	J40116	J41766	00007	00010
PVC1-XXX	L3101VC1-FPP	L3201VC1-FPP	L3300V01-FPP	J60524	41715	00007	00010
KTC1-XXX	L3101TC1-PVD	L3201TC1-PVD	L3300T01-PVD	J60716	J61020	00010	00010
KHC1-XXX	L3101HC1-PVD	L3201HC1-PVD	L3300H01-PVD	J60717	J61110	00010	00010
KVC1-XXX	L3101VC1-PVD	L3201VC1-PVD	L3300V01-PVD	J60718	J61088	00010	00010
VTC1-XXX	L3101TC1-PVC	L3201TC1-PVC	L3300T01-PVC	J60716	J41996	00007	00010
VHC1-XXX	L3101HC1-PVC	L3201HC1-PVC	L3300H01-PVC	J60717	41693	00007	00010
VVC1-XXX	L3101VC1-PVC	L3201VC1-PVC	L3300V01-PVC	J61237	41713	00007	00010
PTC3-XXX	L3101TC3-FPP	L3201TC3-FPP	L3300T03-FPP	J40212	J41872	J00023	00008
PHC3-XXX	L3101HC3-FPP	L3201HC3-FPP	L3300H03-FPP	J40117	J41767	J00023	00008
PVC3-XXX	L3101VC3-FPP	L3201VC3-FPP	L3300V03-FPP	J60509	41716	J00023	00008
KTC3-XXX	L3101TC3-PVD	L3201TC3-PVD	L3300T03-PVD	J60728	J61021	00008	00008
KHC3-XXX	L3101HC3-PVD	L3201HC3-PVD	L3300H03-PVD	J60729	J61201	00008	00008
KVC3-XXX	L3101VC3-PVD	L3201VC3-PVD	L3300V03-PVD	J60730	J61086	00008	00008
VTC3-XXX	L3101TC3-PVC	L3201TC3-PVC	L3300T03-PVC	J60728	J41873	J00023	00008
VHC3-XXX	L3101HC3-PVC	L3201HC3-PVC	L3300H03-PVC	J60729	J41694	J00023	00008
VVC3-XXX	L3101VC3-PVC	L3201VC3-PVC	L3300V03-PVC	J60730	J41714	J00023	00008
PTCJ-XXX	L3101TCJ-FPP	L3201TCJ-FPP	L3300T01-FPP	J40211	J61098	L9904300-PVC	00010
KTCJ-XXX	L3101TCJ-PVD	L3201TCJ-PVD	L3300T01-PVD	J60716	J61020	L9904300-PEW	00010
VTCJ-XXX	L3101TCJ-PVC	L3201TCJ-PVC	L3300T01-PVC	J60716	J41996	L9904300-PVC	00010

NOTE: This guide provides a quick reference and does not cover all configurations or options.

Aftermarket

- KOPkits
- Gauges
- Dampeners
- Pressure Relief Valves
- Tanks
- Pre-Engineered Systems
- Process Controllers (PULSAblue, MicroVision)



sales@novatech-usa.com
www.novatech-usa.com
 Tel: (866) 433-6682 Fax: (866) 433-6684
 Tel: (281) 359-8538 Fax: (281) 359-0084