



## PERMANENT

### Drain Pan Restoration

Restoring your drain pan with Pancrete is cost-effective and simple. Most units are back in service in just a few hours. Experience the ease, savings, and durability of Pancrete – the ultimate choice for ensuring the longevity and efficiency of drain pans.



### Why Choose Pancrete?

Pancrete mixes as a liquid that pours over the old drain pan. The liquid self-levels, and then quickly hardens to form a strong, durable surface. Pancrete is hydrophobic, resistant to chemical corrosion, and stronger than the original pan. Pancrete is the ultimate solution to repairing drain pans, adding years to the life of a viable HVAC unit or cooling tower.

- Pours over the old pan
- Self-leveling
- Stops damaging leaks
- Strengthens pans
- Repels water
- Corrosion resistant
- Adds years to unit
- Permanent solution
- Self-adhering

The smooth, level surface of Pancrete allows for easy cleaning and consistent water flow. Unleveled surfaces allow water to pool and become stagnant. These areas provide an environment for microbial growth, resultant odors, and corrosion. The self-leveling capability of Pancrete eliminates elevations and valleys where water pooling can occur, effectively preventing the growth and action of bacterial and fungal odors.



Part #	Makes	Coverage
PCQ	1 Quart	1.25 Sq ft
PC1	1 Gallon	5 Sq ft
PC2	2 Gallons	10 Sq ft
PC5	5 Gallons	25 Sq ft

### How much Pancrete?

Pancrete is calculated at 1/4" depth. Measure the drain pan length and width to find the square footage of the pan. Refer to the chart below to determine how much Pancrete is needed.

\*Note: Older condensate pans will have corroded spots, dips, high spots, and valleys causing the installation to require more or less product. Pancrete pours seamlessly on top of itself in case more is needed.

Didn't pour enough? No worries, Pancrete is self-adhering. You can pour on top of previous applications.



For a full **Restoration** use **V570** to coat **curved** and **vertical** surfaces.

1-800-766-9057

CS@cleanac.com

PANCRETE.COM