

GETTING STARTED

1. Remove the battery door .
2. Insert 2 new AAA size batteries in battery compartment, and press [RESET] key to reset the clock.
3. Close the battery door.
4. When the batteries are inserted, all the segments of the display will be shown briefly before entering the radio controlled time reception mode.
5. Clock will automatically start scanning for the radio controlled time signal after 8 seconds.

FUNCTION KEYS

[SNOOZE I LIGHT] key: Press to turn on backlight for 5 seconds. Press to stop current alarm when it is sounding.

[MODE] key: Switch between normal time mode and alarm time mode.

[ALM ON/OFF] key: In normal time mode or alarm time mode, press and hold it for 3 seconds to enter the setting mode. Press it to turn on/off alarm.

[ADJUST] key: Toggle between Month/Date and Year display. In setting mode, press to change setting values.

[RECEIVE] key: Press to switch between °C/°F. Press and hold for 3 seconds to receive signal for reception testing.

[RESET] key: Press to return all values to default values. In case of malfunction, the unit may be required to reset.

DISPLAY SYMBOLS



Normal Time Mode


1. Time
2. Date/ Month
3. Day of the Week
4. Time zone map
5. Daylight Saving Time
6. Signal Strength Indicator
7. Temperature

Alarm Time Mode

1. Alarm time
2. Alarm icon
3. Snooze icon
4. Alarm mode

PRODUCT DESCRIPTIONS

1. [SNOOZE/LIGHT] key
2. LCD Display
3. [MODE] key
4. [ALM ON/OFF] key
5. [RECEIVE] key
6. [ADJUST] key
7. [RESET] key
8. Battery Compartment



DAYLIGHT SAVING TIME (DST)

The clock has been programmed to automatically switch when daylight savings time is in effect. Your clock will show "DST" during the summer.

SETTING THE TIME ZONE

1. In the normal time display, press the [MODE] key to enter the alarm time mode.
2. Press the [ADJUST] key to set the desired time zone. Refer to the Time Zone map on display, P=Pacific, M=Mountain, C=Central, and E=Eastern.
3. Press the [MODE] key to return to normal time mode .

SIGNAL STRENGTH INDICATOR

The signal indicator displays signal strength in 4 levels. Wave segment flashing means time signals are being received. The signal quality is classified into 4 types:



If the clock receives signal successfully, a sync-time symbol "⌚" will appear on LCD. Otherwise the antenna segment will not show on the LCD.

Note: You may press [RECEIVE] key to receive time signal manually. The receive mode stops automatically after 6-12 minutes. The receive mode consumes more battery power and may reduce battery life.

SETTING THE TIME AND DATE

The clock will automatically synchronize with the exact time and calendar. If you are out of reach of the Radio Controlled transmitter or if the reception is not reachable, the time and calendar can also be set manually.

1. Press the [ALM ON/OFF] key for 3 seconds until the HOUR digit flashes.
2. Press the [ADJUST] key to set the desired hour.
3. Repeat the above operations to set time, 12-24hour format, year, month, and date: Hour → Minute → Second → 12/24 Hour format → Year → Month → Date.
4. Press the [MODE] key to save and exit setting mode.

