

Lovibond® Water Testing

Tintometer® Group



- GLP features
- Easy calibration against air
- Data storage
- Auto hold function
- Backlit display
- Alarm function (Min/Max)



The portable meter SD 310 Oxi meets the day-to-day demands for sturdy and reliable measurement of dissolved oxygen and completes the SD 300 series

SD 310 Oxi

Parameter

- Dissolved oxygen (O₂)
- O₂-Concentration in mg/l
- O₂-Saturation in %
- Temperature in °C/°F

Applications

- Drinking/ potable water
- Waste Water
- Surface Water

Users

- Water Treatment Companies
- Industrial and Governmental Laboratories
- Sewage Plants
- Water Protection Control

www.lovibond.com

novatech
INTERNATIONAL

sales@novatech-usa.com
www.novatech-usa.com
Tel: (866) 433-6682 Fax: (866) 433-6684
Tel: (281) 359-8538 Fax: (281) 359-0084

Technical Data

O₂ concentration	0.0 ... 70.0 mg/l
O₂ partial pressure	0 ... 1200 hPa O ₂ 0.0 ... 427.5 mm Hg
O₂ saturation	0 ... 600 %
Ambient air pressure	10...1.200 hPA abs.
Sensor temperature	- 5 ... 50 °C = 23 ... 122 °F
Accuracy O₂ concentration	0 ... 25 mg/l ± 1.5% ± 0.2 mg/l 25 ... 70 mg/l ± 2.5% ± 0.3 mg/l
Temperature accuracy	± 0.1 °C
Ambient air pressure accuracy	3 hPa bzw. 0.1 % full scale (higher value relevant)
Ambient conditions sensor	0 to 40 °C = 32 to 104 °F 0 to 95% relative density (non-condensing)
Storage temperature	Instrument: - 25 ... 70 °C = - 13 ... 158 °F Sensor: 0 ... 40 °C = 32 ... 104 °F
Nominal temperature	25 °C
Display	Backlit LCD
Data storage	1,000 data sets manually 8,000 data sets cyclically
Power supply	2 x AAA Batteries
Dimensions	164 x 98 x 37 mm (H x W x D) protective armouring
Weight	287 g incl. batteries and protective armouring
Power consumption	6.25 mA (with Out = Off, corresponding to 160 h), backlight: 10 mA (switches off automatically)
Auto-Off	0 - 120 minutes
Electrode connection	7-pin bayonet connection. Interface/ ext. supply: 4-pin bayonet connection for serial interface and supply

CE-Conformity

Features

Measurement of: Oxygen partial pressure, Oxygen Concentration, Oxygen Saturation, Temperature measurement
Automatic absolute air pressure measurement
Auto Hold Function
Alarm Function
Data Logger + Software
Easy calibration against oxygen in air
Salinity correction
Self-polarising galvanic oxygen probe (Clark), allows instant measurement after system is switched on
Low battery and battery change indicator
Sensor evaluation after calibration in the display
Shock-absorbing rubber protective armouring
Waterproof IP 65 and IP 67

SD 310 Oxi

The portable meter SD 310 Oxi meets the day-to-day demands for sturdy and reliable measurement of dissolved oxygen and completes the SD 300 series.

The well-known Clark-oxygen-sensor with integrated temperature compensation allows instant measurement without the need for time-consuming polarisation.

A direct, convenient user interface facilitates meter operation both outdoors and in the laboratory.

The automatic hold function "freezes" measuring data in the display, and makes them easy to read.

The internal memory allows storage of up to 1,000 data sets. Also an internal data logger enables continuous monitoring of measurement results. Monitoring becomes even more convenient with the alarm function.

The water-tight housing (IP 65 & IP 67) together with the rugged and protective armour ensures reliable operation even in extreme ambient conditions.

The support can be flipped up to hang the meter on pipes or branches or for fastening to a belt.

