

Lovibond® Water Testing

Tintometer® Group



TB 211 IR

with USB interface



The compact Lovibond® infrared turbidity measuring instruments TB 211 IR & TB 210 IR for fast and accurate on-site analysis. It is measured as provided in EN ISO 7027, the scattered light at an angle of 90°.

The wide measuring range from 0.01 to 1100 TE / F = NTU = FNU with a detection limit of 0.01 NTU allows the use of the device in different areas, from drinking water to wastewater.

Since the measurements are made by means of infrared light, both colored and colorless water samples can be measured. A direct transfer of the measurement results to a PC is through the USB interface TB 211 IR easy to set up. The necessary USB cable is already part of the delivery.

- USB interface
- Range 0.01 - 1100 NTU
- Measurement according to EN ISO 7027
- Measurement with infrared light at an angle of 90°

Part Number: 266030

Industry

Chemical Industry | Industries Others | Marine Industry | Municipalities | NGO | Oil and Gas | Pool Public | Pool Services

TB 211 IR

A compact instrument for reliable and easy determination of turbidity. A ring memory with 125 data sets and a USB interface guarantee an efficient data management.

Measuring Range

| Test Name | Measuring Range |
|-----------|-----------------|
| Turbidity | 0.01 - 1100 NTU |

Technical Data

| | |
|---------------------------------|--|
| Optics | temperaturecompensated LED ($\lambda = 860$ nm) and photosensor amplifier in water proof sample chamber, infrared light |
| Accuracy | ± 2.5 % of reading, or ± 0.01 NTU, whichever is bigger, in the range of 0.01 - 500 NTU ; ± 5 % of reading in the range of 500 - 1000 NTU |
| Operation | polycarbonate membrane, splash proof |
| Display | backlit LCD |
| Suitable Vials | Round Cuvettes 24 mm |
| Interfaces | Micro-USB |
| Internal Storage | internal ring memory for 125 data sets |
| Power Supply | 9 V-block |
| Auto – OFF | Yes |
| Measuring Principle | nephelometric (90° scattered light) |
| Measuring Range | 0,01-1100 NTU (Autorange) |
| Clock | Real Time Clock and Date |
| Portability | Portable |
| Environmental Conditions | 5 - 40 °C at 30 - 90 % relative humidity (non condensing) |
| Compliance | CE |
| Dimensions | 110 x 55 x 190 mm |
| Weight | 400 g (Basic unit) |
| Weight with Packaging | (Basic unit) |

Delivery Scope

- Instrument in carrying case
- 4 turbidity standards (< 0,1, 20, 200 and 800 NTU)
- 9 V battery
- 2 vials (\varnothing 24 mm) with lids
- USB cable 1.5 m
- Warranty information
- Certificate of Compliance
- Instruction Manual

Accessories

| Title | Part Number |
|--|-------------|
| Formazin Stock Solution (4000 NTU), 125 ml | 194141 |
| Formazin Stock Solution (4000 NTU), 250 ml | 194142 |
| Set turbidity standards T-CAL (<0.1, 20, 200, 800 NTU) | 194150 |
| Battery 9 V | 1950012 |
| Cleaning cloth | 197635 |
| Sample cuvettes with black lid, Height 55 mm, \varnothing 24 mm, set of 12 | 197655 |
| Sample chamber lid | 19801119 |
| USB cable 1.5 m, for TB 211 IR | 19802509 |

Tintometer GmbH

Lovibond® Water Testing
Schleefstraße 8-12
44287 Dortmund
Tel.: +49 (0)231/94510-0
Fax: +49 (0)231/94510-30
sales@tintometer.de
www.lovibond.com
Germany

Tintometer China

Room 1001, China Life Tower
16 Chaoyangmenwai Avenue,
Beijing, 100020
Tel.: +86 10 85251111 App. 330
Fax: +86 10 85251001
chinaoffice@tintometer.com
www.lovibond.com
China

Tintometer Inc.

6456 Parkland Drive
Sarasota, FL 34243
Tel: 941.756.6410
Fax: 941.727.9654
sales@tintometer.us
www.lovibond.com
USA

The Tintometer Limited

Lovibond House
Sun Rise Way
Amesbury, SP4 7GR
Tel.: +44 (0)1980 664800
Fax: +44 (0)1980 625412
water.sales@tintometer.com
www.lovibond.com
UK

Tintometer South East Asia

Unit B-3-12, BBT One Boulevard,
Lebuh Nilam 2, Bandar Bukit Tinggi,
Klang, 41200, Selangor D.E
Tel.: +60 (0)3 3325 2285/6
Fax: +60 (0)3 3325 2287
lovibond.asia@tintometer.com
www.lovibond.com
Malaysia

Tintometer India Pvt. Ltd.

Door No: 7-2-C-14, 2nd, 3rd & 4th Floor
Sanathnagar Industrial Estate,
Hyderabad, 500018
Telangana
Tel: +91 (0) 40 23883300
Toll Free: 1 800 599 3891/ 3892
indiaoffice@tintometer.com
www.lovibondwater.in
India

Tintometer AG

Hauptstraße 2
5212 Hausen AG
Tel.: +41 (0)56/4422829
Fax: +41 (0)56/4424121
info@tintometer.ch
www.tintometer.ch
Switzerland

Tintometer Brazil

Caixa Postal: 271
CEP: 13201-970
Jundiaí – SP
Tel.: +55 (11) 3230-6410
sales@tintometer.com.br
www.lovibond.com.br
Brazil

Tintometer Spain

Postbox: 24047
08080 Barcelona
Tel.: +34 661 606 770
sales@tintometer.es
www.lovibond.com
Spain