

DROP TEST

SODIUM NITRITE (1 drop = 100 ppm)

Instr. #5043

COMPONENTS:

1 x 4026	Dipper, plastic, large
1 x 4086	Stirring Rod, 5", plastic
1 x 5043	Instruction
1 x 9010	Pipet, Calibrated 0.5 & 1.0 mL, plastic w/red cap
1 x 9198R	Sample Tube, Graduated, 25 mL, plastic w/cap and red dot
1 x R-0730-C	Permanganate Reagent, 2 oz
1 x R-0781-II	Acid Sulfate, 50 g

TO ORDER REPLACEMENT PARTS AND REAGENTS CALL TOLL-FREE 800-TEST KIT (800-837-8548).

PROCEDURE:

**CAREFULLY READ AND FOLLOW PRECAUTIONS ON REAGENT LABELS.
KEEP REAGENTS AWAY FROM CHILDREN.**

1. Rinse and fill 25 mL sample tube (#9198R) to 25 mL mark with water to be tested (Fig. 1).
2. Using the large dipper (#4026), add 1 dipper R-0781 Acid Sulfate. Stir with rod (#4086) to dissolve.
3. Using a 1.0 mL pipet (#9010), add R-0730 Permanganate Reagent dropwise, swirling and counting after each drop, until color changes from colorless to a faint but permanent pink (Fig. 2), which persists for at least 1 minute. Always hold pipet in vertical position.
4. Multiply drops of R-0730 Permanganate Reagent by 100. Record as parts per million (ppm) sodium nitrite.

NOTE: For results as nitrite, multiply sodium nitrite concentration by 0.67.



Fig. 1



Fig. 2



31 Loveton Circle, Sparks, MD 21152 U.S.A.
800-TEST KIT (837-8548) • 410-472-4340