

## DROP TEST

### P/M & P/T ALKALINITY (1 drop = 10 ppm)

**COMPONENTS:**

- |               |  |
|---------------|--|
| 1 x 5067G     | Instruction  |
| 1 x 9198G     | Sample Tube, Graduated (25 mL) w/ cap & green dot, plastic |
| 1 x R-0637-C  | Methyl Orange Indicator, 2 oz, DB                          |
| 1 x R-0638G-A | Phenolphthalein Indicator, .75 oz w/ green cap, DB         |
| 1 x R-0645-C  | Total Alkalinity Indicator, 2 oz, DB                       |
| 1 x R-0687G-C | Sulfuric Acid .12N, 2 oz w/ green cap, DB                  |

**TO ORDER REPLACEMENT PARTS AND REAGENTS CALL TOLL-FREE  
800-TEST KIT (800-837-8548).**

**PROCEDURE:**

**CAREFULLY READ AND FOLLOW PRECAUTIONS ON REAGENT LABELS.  
KEEP REAGENTS AWAY FROM CHILDREN.**

NOTE: When dispensing reagents from dropper bottles, **always** hold bottle in a vertical position.

**P/M Alkalinity Test**

1. Rinse and fill 25 mL sample tube (#9198G) to 25 mL mark with water to be tested.

NOTE: For results in grains per gallon (gpg), fill to 14.6 mL mark.

2. Add 3 drops R-0638G Phenolphthalein Indicator. Swirl to mix. Sample will turn pink (Fig. 1) if P alkalinity is present—proceed to Step 3. If sample is colorless, proceed to Step 4.
3. Add R-0687G Sulfuric Acid .12N dropwise, swirling and counting after each drop, until color just changes from pink to colorless. Record drops as P reading.

4. Add 5 drops R-0637 Methyl Orange Indicator. Swirl to mix. Sample will turn yellow (Fig. 2).

5. Add R-0687G Sulfuric Acid .12N dropwise, swirling and counting after each drop, until color changes from yellow to orange (salmon pink) (Fig. 3). Record total drops (Steps 3 & 5) as M reading.

6. Multiply P reading by 10. Record as parts per million (ppm) P alkalinity as calcium carbonate. Multiply M reading by 10. Record as ppm M alkalinity as calcium carbonate.

NOTE: For 14.6 mL sample, record P reading as grains per gallon (gpg) P alkalinity as calcium carbonate. Record T reading as gpg T alkalinity as calcium carbonate.

(OVER)



Fig. 1



Fig. 2



Fig. 3

## DROP TEST

### P/M & P/T ALKALINITY (1 drop = 10 ppm)

Instr. #5067G

#### P/T Alkalinity Test

1. Rinse and fill 25 mL sample tube (#9198G) to 25 mL mark with water to be tested.

NOTE: For results in grains per gallon (gpg), fill to 14.6 mL mark.

2. Add 3 drops R-0638G Phenolphthalein Indicator. Swirl to mix. Sample will turn pink (Fig. 4) if P alkalinity is present—proceed to Step 3. If sample is colorless, proceed to Step 4.

3. Add R-0687G Sulfuric Acid .12N dropwise, swirling and counting after each drop, until color just changes from pink to colorless. Record drops as P reading.

4. Add 5 drops R-0645 Total Alkalinity Indicator. Swirl to mix. Sample will turn green (Fig. 5).

5. Continue adding R-0687G Sulfuric Acid .12N dropwise, swirling and counting after each drop, until color changes from green to red (Fig. 6). Record total drops (Steps 3 & 5) as T reading.

6. Multiply P reading by 10. Record as parts per million (ppm) P alkalinity as calcium carbonate. Multiply T reading by 10. Record as ppm T alkalinity as calcium carbonate.

NOTE: For 14.6 mL sample, record P reading as grains per gallon (gpg) P alkalinity as calcium carbonate. Record T reading as gpg T alkalinity as calcium carbonate.



Fig. 4



Fig. 5



Fig. 6



31 Loveton Circle, Sparks, MD 21152 U.S.A.  
800-TEST KIT (837-8548) • 410-472-4340

## DROP TEST

### TOTAL HARDNESS (1 drop = 10 ppm)

Instr. #5067B

#### COMPONENTS:

1 x 5067B	Instruction
1 x 9198B	Sample Tube, Graduated (25 mL) w/ cap & blue dot, plastic
1 x R-0619B-C	Hardness Buffer, 2 oz w/ blue cap, DB
1 x R-0620B-I	Hardness Indicator Powder, 10 g w/ blue dot
1 x R-0683-C	Hardness Reagent, 2 oz, DB

TO ORDER REPLACEMENT PARTS AND REAGENTS CALL TOLL-FREE  
800-TEST KIT (800-837-8548).

#### PROCEDURE:

CAREFULLY READ AND FOLLOW PRECAUTIONS ON REAGENT LABELS.  
KEEP REAGENTS AWAY FROM CHILDREN.

NOTE: When dispensing reagents from dropper bottles, **always** hold bottle in a vertical position.

#### Total Hardness Test

1. Rinse and fill 25 mL sample tube (#9198B) to 25 mL mark with water to be tested (Fig. 1).
2. Add 5 drops R-0619B Hardness Buffer. Swirl to mix.
3. Add 1 dipper R-0620B Hardness Indicator Powder. Swirl until dissolved. Sample will turn red (Fig. 2) if hardness is present.
4. Add R-0683 Hardness Reagent dropwise, swirling and counting after each drop, until color changes from red to blue (Fig. 3).

5. Multiply drops of R-0683 Hardness Reagent by 10. Record as parts per million (ppm) total hardness as calcium carbonate.



Fig. 1



Fig. 2



Fig. 3



31 Loveton Circle, Sparks, MD 21152 U.S.A.  
800-TEST KIT (837-8548) • 410-472-4340

## DROP TEST SODIUM SULFITE (1 drop = 10 ppm)

Instr. #5067W

### COMPONENTS:

1 x 5067W	Instruction
1 x 9198W	Sample Tube, Graduated (25 mL) w/ cap & white dot, plastic
1 x R-0638W-C	Phenolphthalein Indicator, 2 oz w/ white cap, DB
1 x R-0699-C	Iodide Iodate Reagent, 2 oz, DB
1 x R-0725-I	Acid Starch Indicator Powder, 10 g

TO ORDER REPLACEMENT PARTS AND REAGENTS CALL TOLL-FREE  
800-TEST KIT (800-837-8548).

### PROCEDURE:

**CAREFULLY READ AND FOLLOW PRECAUTIONS ON REAGENT LABELS.  
KEEP REAGENTS AWAY FROM CHILDREN.**

NOTE: When dispensing reagents from dropper bottles, **always** hold bottle in a vertical position.

#### Sodium Sulfite Test

NOTE: Sample must be cooled to less than 100°F (38°C) to prevent high test results. Sample must be protected from air contact while cooling to prevent low test results.

1. Collect water to be tested in a clean, preferably large-mouthed, bottle to overflowing. Immediately cap and cool to room temperature.
2. Rinse and fill 25 mL sample tube (#9198W) to 25 mL mark with cooled (room temperature) water to be tested (Fig. 1).

NOTE: For results in grains per gallon (gpg), fill to 14.6 mL mark.

3. Add 1 drop R-0638W Phenolphthalein Indicator. Swirl to mix. Sample will turn pink (Fig. 2).

4. Add R-0725 Acid Starch Indicator Powder a dipper at a time, swirling after each dipper, until color changes from pink to colorless. Add 2 more dippers. Swirl until dissolved.

5. Add R-0699 Iodide Iodate Reagent dropwise, swirling and counting after each drop, until sample changes from colorless to a faint but permanent blue (Fig. 3).

6. Multiply drops of R-0699 Iodide Iodate Reagent by 10. Record as parts per million (ppm) sodium sulfite.

NOTE: For 14.6 mL sample, record drops as grains per gallon (gpg) sodium sulfite.

NOTE: For results as sulfite, multiply sulfite concentration by 0.64.



Fig. 1



Fig. 2




Fig. 3



31 Loveton Circle, Sparks, MD 21152 U.S.A.  
800-TEST KIT (837-8548) • 410-472-4340